



## ***Draft Gear Cushion Lifter Cart***

***Part # CCL-IPS***



The IPS **Draft Gear Cushion Lifter Cart** is a mobile lifting device with the following characteristics:

<b>Wt:</b>	507 lbs.
<b>Dim.:</b>	64" wide x 63" long x 8-1/2" high (@ rest, above rail) to 31" high (raised, above rail)
<b>WLL:</b>	800 lbs.
<b>Power Pack:</b>	120 V
<b>Wheels:</b>	5" Aluminum

### **SAFETY, MAINTENANCE & OPERATING GUIDELINES –**

#### **PLEASE READ IN CONJUNCTION WITH POWER-PACK GUIDE BEFORE USE:**

- 1. Inspect** the cushion lifter before each use to ensure this it is in good working order. **Do not use** if damaged, or if hydraulic fluid is leaking from the power pack or hydraulic lines.
- 2.** Check the level of **hydraulic fluid** in the tank on a monthly basis; top up with AW-68 as required.
- 3.** When raising or lowering the table, do not place fingers, hands or feet between the table and the frame – this is a "**Crush Zone**" and may result in severe injury if the table drops unexpectedly.
- 4.** When raising and lowering the cushion lifter, **stand clear** of the table and **use the pendant** to safely raise and lower the table.
- 5.** It is the responsibility of the user to ensure that the load on the table is **properly balanced and secured** before raising and lowering the table. Unbalanced or insecure loading may result in serious injury.
- 6.** Always **engage the parking brake** when raising and lowering the table. Failure to do so could result in unexpected cart movement and serious injury.
- 7.** The cushion lifter is designed for a **maximum capacity** of **800 lbs.** ; exceeding the maximum load capacity may result in serious damage and/or injury.
- 8.** In the event of damage to the cushion lifter, contact **IPS** at **604-465-8994** for replacement parts, repairs, or servicing.